

NORMAL CHECKLIST BOEING REV 1.0.3 - FEBRUARY '24

PREFLIGHT	AFTER TAKEOFF	
DXYGEN TESTED 100%	ENGINE BLEEDS	ON
NAVIGATION TRANSFER AND DISPLAY SWITCHES NORMAL, AUTO		AUTO UP and OFF
WINDOW HEATON		
PESSURIZATION MODE SELECTOR AUTO		UP, NO LIGHTS
FLIGHT INSTRUMENTS HEADING , ALTIMITER	DESCENT	
PARKING BRAKE SET	PRESSURIZATION	LAND ALT
ENGING START LEVERS	RECALL	CHECKED
	AUTOBRAKE	
BEFORE START	LANDING DATA	VREF, MINIMUMS
FLIGHT DECK DOOR CLOSED AND LOCKED	APPROACH BRIEFING	COMPLETED
TUEL KGS, PUMPS ON	ADDI	204611
PASSENGER SIGNS	APPROACH ALTIMITERS	
VINDOWS LOCKED	ALIMITERS	
ACPV2, HEADING, ALTITUDE	LANDING	
GROSS WEIGHT CDU, OFP	ENGINE START SWITCHES	CONT
AKEOFF SPEEDS	SPEEDBRAKE	ARMED
DU PREFLIGHTCOMPLETED	LANDING GEAR	DOWN
RUDDER AND AILERON TRIM FREE AND ZERO	FLAPS	, GREEN LIGHT
AXI AND TAKEOFF BRIEFING COMPLETED	SHUTDOWN	
NTI COLLISION LIGHT ON		OFF
BEFORE TAXI	YF804-YV652 (SB CHANGES YB521 - YF803)	
ENERATORS ON	(SB CHANGES YB521 - YF803)	AUTO
ROBE HEAT ON	PROBE HEAT	OFF
NTI-ICE	HYDRAULIC PANEL	SET
SOLATION VALVE AUTO	FLAPS	UP
NGINE START SWITCHES	PARKING BRAKE	· · · · · · · · · · · · · · · · · · ·
ECALL	ENGINE START LEVERS	CUTOFF
UTO BRAKE RTO	WEATHER RADAR	OFF
LAPS, GREEN LIGHT	SEC	CURE
·		OFF
NGINE START LEVERS	EMERGENCY EXIT LIGHTS	OFF
ELIGHT CONTROLS CHECKED	WINDOW HEAT	OFF
GROUND EQUIPMENT	PACKS	OFF
BEFORE TAKEOFF	EFB	OFF

EMERGENCY EVACUATION		
AIRCRAFT PARKING UPWIND	ENGINE START LEVERSOFF	
FLAPS	FIRE EXTINGUISHERS (ALL : ENG and APU) PULL	
PARKING BRAKE SET	■ If Evacuation required:	
ATC (VHF 1) ADVISED	- EVACUATION INITIATE	
CABIN CREW (PA)INFORMED	■ If Evacuation not required:	
CABIN PRESSURE VERIFY ZERO If not zero, MODE SEL on MANUAL, VALVE OPEN	- CABIN CREW and PASSENGERS (PA) NOTIFY	

